

WATER TEMPERATURE SENDER
WATER TEMPERATURE SWITCH
ALTERNATOR, 50A-12VDC
GLOW PLUGS
PREHEAT SOLENOID
OIL PRESSURE SWITCH
FUEL SOLENOID
OIL PRESSURE SENDER
EXHAUST TEMPERATURE SWITCH
20A CIRCUIT BREAKER-12VDC
10A CIRCUIT BREAKER-24VDC
BATTERY SWITCH
12-24 VDC
STARTER MOTOR
AUX. OIL PRESSURE SWITCH
FUEL PUMP
EMERGENCY STOP SWITCH
TB2
TB1
K2
K1
FUSE 8A
RD/WH
WH
YL/RD
WH/RD
RD/VL
BK
OG
YL
BK/WH
TB2-1
TB2-2
TB1-5
TB1-3
TB1-2
TB1-10
TB2-4
TB2-5
TB2-8
ALTERNATOR, 35A-24VDC
BALLAST RESISTOR
#14 PUR
#14 GRN
#14 RED
#14 BLK
FIELD
OUT
#10 BLK TO GRND. SOL.
#10 ORN TO STARTER
TO VOLTAGE REGULATOR
OIL PRESSURE
WATER TEMP
HOUR METER
VOLT METER
PREHEAT SWITCH
START SWITCH
STOP SWITCH
INSTRUMENT PANEL
BATTERY 12-24VDC
CIRCUIT BREAKER
BATTERY SWITCH
STARTER
GROUND SOLENOID
STARTER SOLENOID
EMERGENCY STOP SWITCH
GLOWPLUGS
PREHEAT SOLENOID
ALTERNATOR
K1-START
K2-RUN
FUEL SOL.
FUEL PUMP
EXH. TEMP. SW.
WATER TEMP. SW.
OIL PRESS. SW.
1N4002
K2-RUN RELAY
K1-START RELAY
STOP SWITCH
PREHEAT SWITCH
START SWITCH
OIL PRESS. SENDER
WATER TEMP. SENDER
AUX. O.P. SWITCH
HOURMETER
VOLTMETER
OIL PRESS. GAUGE
WATER TEMP. GAUGE
TOLERANCES
WESTERBEKE CORPORATION
AVON MA. 02322
WIRING DIAGRAM/ SCHEMATIC 8.0 BTDA, 10.0 BTDA, 12.5 BTDB, 15.0 BTDC UNGND
E
43388